
NON-RESETTABLE WIRING

Battery or Distribution Panel



Important: Proper wiring must be followed!
Improper wiring may cause damage to switch